

PRESS INSTRUCTIONS FOR DIRECT TO FILM FULL COLOR TRANSFERS

- **Pre-press garment at 329 degrees for 20 seconds to remove wrinkles and moisture**
- **Position the transfer to desired location on the garment**
- **Press at 329 degrees for 20 seconds with firm pressure**
- **Allow transfer to cool completely before removing the carrier film**
- **Press for an additional 20 seconds, parchment paper or heat resistant sheet NOT needed**

Heat Press highly recommended